



USER MANUAL

FOR DOOSAN ROBOTS

ORIGINAL INSTRUCTION (EN)

v1.02

Contents

Contents	2
1 Introduction	4
1.1 Important Safety Notice	4
1.2 Scope of the Manual.....	4
1.3 Naming convention	4
1.4 How to read the Manual	5
2 Safety.....	6
2.1 Intended Use	6
2.2 General Safety Instructions	7
2.3 Risk Assessment.....	8
2.4 Environmental Safety	8
2.5 PLd CAT3 Safety Function.....	9
3 Operation mode(s)	10
4 Installation	11
4.1 Overview.....	11
4.2 Mounting.....	11
4.2.1 Quick Changer options	12
4.2.2 Tools	14
4.3 Wiring	18
4.3.1 Tool data	18
4.3.2 Digital I/O wires.....	18
4.3.3 Ethernet cable	21
4.3.4 Power supply.....	21
5 Operation.....	23
5.1 Overview.....	23
5.2 Ethernet Interface setup	24
5.3 Web Client	26
5.4 OnRobot WebLogic menu	28
5.4.1 Browser	28
5.4.2 Program Editor	29
6 Additional Software Options.....	35
6.1 Compute Box	35
6.1.1 Interfaces.....	35
6.1.2 Web Client.....	35
6.2 Modbus TCP.....	51
6.2.1 Settings.....	51
6.2.2 Function codes	52
6.2.3 Registers.....	52

7	Hardware Specification	63
7.1	Technical sheets	63
7.2	Mechanical Drawings	89
7.2.1	Adapter plate(s)	89
7.2.2	Mountings	89
7.2.3	Tools	92
7.3	Center of Gravity	99
8	Maintenance	100
9	Warranties	103
9.1	Patents	103
9.2	Product Warranty	103
9.3	Disclaimer	103
10	Certifications	104

1 Introduction

1.1 Important Safety Notice



DANGER:

You must read, understand, and follow all safety information in this manual, and the robot manual and all associated equipment before initiating robot motion. Failure to comply with safety information could result in death or serious injury.

1.2 Scope of the Manual

The manual covers the following OnRobot products and its components:

Grippers	Version
Gecko Gripper	v2
RG2	v2
RG2-FT	v2
RG6	v2
VG10	v2

Sensors	Version
HEX-E QC	v3
HEX-H QC	v3

Where applicable the combination of the products is also covered in the manual.



NOTE:

Generally, the products without the Quick Changer v2 interface, are not in the scope of this manual.

1.3 Naming convention

In the user manual Gecko Gripper is called Gecko only.

The RG2 and RG6 names as model variants are used separately or together as RG2/6 if the information is relevant for both variants.

The HEX-E QC and HEX-H QC names as model variants are used separately or together as HEX-E/H QC if the information is relevant for both variants.

1.4 How to read the Manual

The manual covers all OnRobot products and its components that is available for your robot.

To make it easy to follow what type of product (or combination) or component is the given information is relevant for, the following visual highlights are used:

RG2

This is an instruction relevant for the RG2 product only.

RG2-FT

This is an instruction relevant for the RG2-FT product only.

VG10

This is an instruction relevant for the VG10 product.

All text without these visual marks are relevant for all products or components.

For convenience, in each part that contains visual highlights (that span across pages) a table is provided in the beginning, to guide you which page contains the relevant information for your product or component:

 RG2	5
 RG2-FT	5
 VG10	5

2 Safety

The robot integrators are responsible for ensuring that the applicable safety laws and regulations in the country concerned are observed and that any significant hazards in the complete robot application are eliminated. This includes, but is not limited to:

- Performing a risk assessment for the complete robot system
- Interfacing other machines and additional safety devices if defined by the risk assessment
- Setting up the appropriate safety settings in the robot software
- Ensuring that the user will not modify any safety measures
- Validating that the total robot system is designed and installed correctly
- Specifying instructions for use
- Marking the robot installation with relevant signs and contact information of the integrator
- Collecting all documentation in a technical file; including the risk assessment and this manual

2.1 Intended Use

OnRobot tools are intended to be used on collaborative robots and light industrial robots with different payloads depending on the end-of-arm tooling specifications. OnRobot tools are normally used in pick-and-place, palletizing, machine tending, assembly, quality testing and inspection and surface finishing applications.

The end-of-arm tooling should only operate under conditions noted in **Technical sheets** section.

Any use or application deviating from intended use is deemed to be impermissible misuse. This includes, but is not limited to:

- Use in potentially explosive atmospheres
- Use in medical and life critical applications
- Use before performing a risk assessment
- Use outside the permissible operational conditions and specifications
- Use close to a human's head, face and eye area
- Use as a climbing aid

2.2 General Safety Instructions

Generally, all national regulations, legislations and laws in the country of installation must be observed. Integration and use of the product must be done in compliance with precautions in this manual. Particular attention must be paid to the following warnings:



DANGER:

You must read, understand, and follow all safety information in this manual, and the robot manual and all associated equipment before initiating robot motion. Failure to comply with safety information could result in death or serious injury.

The information in this manual does not cover designing, installing, and operating a complete robot application, nor does it cover other peripheral equipment that can influence the safety of the complete system. The complete system must be designed and installed in accordance with the safety requirements set forth in the standards and regulations of the country where the robot is installed.

Any safety information provided in this manual must not be construed as a warranty, by OnRobot A/S, that the robot application will not cause injury or damage, even if robot application complies with all safety instructions.

OnRobot A/S disclaims any and all liability if any of OnRobot tools tooling are damaged, changed or modified in any way. OnRobot A/S cannot be held responsible for any damages caused to any of OnRobot tools tooling, the robot, or any other equipment due to programming errors or malfunctioning of any of OnRobot tools.



WARNING:

OnRobot tools are not allowed to be exposed to condensing conditions when power is on or when connected to a robot. If condensing conditions appear during transport or storage, the product must be placed between 20 and 40 Celsius degrees for 24 hours before power is applied or before connected to a robot.

It is recommended that OnRobot tools are integrated in compliance with the following guides and standards:

- ISO 10218-2
- ISO 12100
- ISO/TR 20218-1
- ISO/TS 15066

2.3 Risk Assessment

The robot integrator must perform a risk assessment on the complete robot application. OnRobot tools are only components in a robot application and therefore they can be only safely operated if the integrator has considered the safety aspects of the whole application. OnRobot tools are designed with relatively smooth and round design with a limited amount of sharp edges and pinch points

In collaborative applications, the trajectory of the robot can play a significant safety role. The integrator must consider the angle of contact with a human body, e.g. orientate OnRobot tools and workpieces so that the contact surface in the direction of movement is as large as possible. It is recommended that the tool connectors are pointed in the direction opposite to the movement.

OnRobot A/S have identified the potential hazards listed below as significant hazards that must be considered by the integrator:


- Objects flying from OnRobot tools due to loss of grip
- Objects falling down from OnRobot tools due to loss of grip
- Injuries due to collisions between humans and workpieces, OnRobot tools tooling, robot or other obstacles
- Consequences due to loosen of bolts
- Consequences if OnRobot tools cable gets stuck to something
- Workpiece itself represents a hazard

2.4 Environmental Safety

OnRobot A/S products must be disposed of in accordance with the applicable national laws, regulations and standards.

The product is produced with restricted use of hazardous substances to protect the environment; as defined by the EU RoHS Directive 2011/65/EU. These substances include mercury, cadmium, lead, chromium VI, polybrominated biphenyls and polybrominated diphenyl ethers.

Observe national [registration](#) requirements for importers according to EU WEEE Directive 2012/19/EU.



2.5 PLd CAT3 Safety Function


RG2
RG6

A safety-rated function has been designed as two buttons at the two arms of the product, conforming to ISO 13849-1 PLd CAT3.

This Safety Function has a max response time of 100 ms and a MTTF of 2883 years.

The behavior of the safety system is described below:

If something activates the two Safety Buttons, see picture below, the safety control system stops motion of the two arms of the product. Motion is then prevented as long as one or both of the two buttons are activated.



PLd CAT3 Safety Buttons

If this happens while running the robot program, user can detect this condition with the help of the provided status information and execute any necessary step on the robot.

To come back to normal operation with the gripper there are provided commands to reset the gripper.



CAUTION:

Before resetting the gripper always make sure that no part will be dropped due to the loss of gripper power. If Dual Quick Changer is used it will cycle the power for both sides.

For further details refer to the Operation section.

3 Operation mode(s)

There is one way how the device(s) could be used:

Mode(s) of Operation	
OnRobot WebLogic <i>required in the robot: digital I/O module</i>	

OnRobot WebLogic

This mode allows simple Digital I/O communication to be used to operate the grippers/sensor.

For example the Compute Box could be easily programmed to:

- when one of the robot digital outputs is set to HIGH, then the RG2 gripper opens to 77mm
- or when the force values measured with the HEX-E QC reach 50N, the Compute Box sends a HIGH digital output to the robot.

The Compute Box has 8 digital inputs and 8 digital outputs that can be freely configured for any "logic".

In this way the user can configure:

- eight gripper/sensor controlling functionality (e.g.: set width to X, close, zero, set preload, etc.)
- and eight gripper/sensor monitoring functionality (e.g.: is grip detected, is preload > 50N, etc.).

Furthermore, the "logic" can be complex, like:

- is grip detected AND force >20 N

These "logics" can be programmed through the Compute Box's web interface called Web Client. It requires only a normal computer with a browser.

In this document this mode of operation will be covered and will be referred to as:

- OnRobot WebLogic

4 Installation

4.1 Overview

For a successful installation the following steps will be required:

- Mount the components
- Wire the cables
- Setup the software

In the following sections, these installation steps will be described.

4.2 Mounting


Required steps:

- Mount the Quick Changer option
- Mount the tool(s)

In the following two subsections these two mounting steps will be described.

4.2.1 Quick Changer options

Quick Changer - Robot Side




Quick Changer - Robot Side

- 1 M6x8mm (ISO14580 8.8)
- 2 Quick Changer (ISO 9409-1-50-4-M6)
- 3 Dowel pin $\varnothing 6 \times 10$ (ISO2338 h8)
- 4 Adapter/ Robot tool flange (ISO 9409-1-50-4-M6)

Use 10 Nm tightening torque.

Dual Quick Changer




Dual Quick Changer

- 1 M6x20mm (ISO14580 8.8)
- 2 Dual Quick Changer
- 3 Dowel pin $\varnothing 6 \times 10$ (ISO2338 h8)
- 4 Adapter/ Robot tool flange (ISO 9409-1-50-4-M6)

Use 10 Nm tightening torque.

HEX-E/H QC



HEX-E/H QC

- 1 HEX-E/H QC sensor
- 2 M4x6mm (ISO14581 A4-70)
- 3 M6x8mm (NCN20146 A4-70)
- 4 HEX-E/H QC adapter
- 5 Adapter/ Robot tool flange (ISO 9409-1-50-4-M6)


Use 1.5 Nm tightening torque. for M4x6mm

Use 10 Nm tightening torque. for M6x8mm

4.2.2 Tools

	Gecko	14
	Quick Changer - Tool side	15
	RG2	15
	RG2-FT.....	16
	RG6	16
	VG10	17

Gecko



Step 1:

Move the tool close to the Quick Changer as illustrated.

The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:

Flip the tool until it is fully mated, and you hear a clicking sound.


To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.



CAUTION:

With a Dual Quick Changer the Gecko Gripper can only be mounted on the Secondary (2) side. Mounting on the Primary (1) side will prevent the devices to function correctly.

Quick Changer -
Tool side



Step 1:

Move the tool close to the Quick Changer as illustrated.


The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:

Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

RG2



Step 1:

Move the tool close to the Quick Changer as illustrated.


The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:

Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

RG2-FT



Step 1:

Move the tool close to the Quick Changer as illustrated.


The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:

Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

RG6



Step 1:

Move the tool close to the Quick Changer as illustrated.


The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:

Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

VG10

**Step 1:**

Move the tool close to the Quick Changer as illustrated.

The hook mechanism (rod and hook tongue) will keep the lower part locked once mounted.

Step 2:


Flip the tool until it is fully mated, and you hear a clicking sound.

To unmount the tool, press the aluminum button on the Quick Changer and repeat the steps in the reverse order.

4.3 Wiring

Four kind of cables have to be connected to wire the system properly:

- Tool data cable between the tool(s) and the Compute Box
- The provided Digital I/O wires between the Compute Box and the robot controller
- Ethernet communication cable between the Compute Box and your computer
- Power supply of the Compute Box



4.3.1 Tool data

Connect the data cable to the tool(s) then route the cable (blue line) to the Compute Box (CB) and use the supplied Velcro tape (black) to fix it.



NOTE:

Leave some extra cable length around the joints so that the cable is not pulled when the robot moves.

Also make sure that the cable bending radius is minimum 40mm (for the HEX-E/H QC it is 70mm)

Then, connect the other end to the Compute Box's DEVICES connector.



CAUTION:

Use only original OnRobot tool data cables.


4.3.2 Digital I/O wires

For Doosan robots, the I/O interface (TBCI 1-2, TBC0 1-2) inside the control cabinet can be used connect the Compute Box to the robot controller.

Installation

Make sure that the robot is powered off completely.

Configure the Compute Box DIP switches (red) to PNP:



For **PNP** type set the 1. and 2. DIP switches to OFF position (down).

DIP switch 1: Digital Input mode


DIP switch 2: Digital Output mode



NOTE:

Do not change the DIP switch 3 and 4 otherwise the network settings will be changed.


Plug in the two green 8 pole pluggable connectors.



The supplied connector type is:

2 x Phoenix Contact MC 1,5/8-ST-3,5 Terminal Block.

Wire the digital I/O wires from the Compute Box to the robot.



DO1-8: Digital outputs of the Compute Box (signals from the grippers/sensor to the robot)

DI1-8: Digital inputs of the Compute Box (signals from the robot to the grippers/sensor)

It is recommended to connect all 8 inputs and 8 outputs for simplicity.



CAUTION:

If some of the DO1-8 or DI1-8 wires will not be connected, make sure to unscrew it from the terminal block to avoid an accidental short circuit.



CAUTION:

The 24V and GND pins are only Reference Voltage Output. It cannot be used to power any equipment.

It is recommended to use the supplied wires only. If it is necessary to use different wire, use one that is shorter than 3 m.

Connect the Compute Box inputs to the robot outputs and the Compute Box outputs to robot inputs.

For simplicity, it is recommended to map the pins in order:

- | | |
|------------------------------------|-------------------------------------|
| DO1 to the robot's Digital input 1 | DI1 to the robot's Digital output 1 |
| DO2 to the robot's Digital input 2 | DI2 to the robot's Digital output 2 |
| ... | ... |
| DO8 to the robot's Digital input 8 | DI8 to the robot's Digital output 8 |


List of the important pins of the IO terminal blocks:



Pin	Description	Pin	Description
I01	Digital input 1	O01	Digital output 1
I02	Digital input 2	O02	Digital output 2
I03	Digital input 3	O03	Digital output 3
I04	Digital input 4	O04	Digital output 4
I05	Digital input 5	O05	Digital output 5
I06	Digital input 6	O06	Digital output 6
I07	Digital input 7	O07	Digital output 7
I08	Digital input 8	O08	Digital output 8
GND	Ground		

Please note which pin you used during the wiring, in a later step it is going to be needed for the mapping.

Use the internal power supply for the robot IO (factory default setting):



To have a common signal ground the following two pins needs to be wired together:

Pins from	Pins to	Description
Compute Box's GND	Robot's GND	Compute Box GND to IN-COM1

4.3.3 Ethernet cable



Connect the provided Compute Box (ETHERNET connector) and your computer with the supplied UTP cable.

This connection is only needed for programming.



CAUTION:

Use only original OnRobot ethernet cables or replace it with one that is shielded and no more than 3 meter long .



WARNING:

Check and make sure that the Compute Box enclosure (metal) and the robot controller enclosure (metal) are not connected (no galvanic connection between the two).

4.3.4 Power supply



Connect the supplied power supply to the Compute Box 24V connector.



NOTE:

To disconnect the power connector make sure to pull the connector housing (where the arrows are shown) and not the cable.



CAUTION:

Use only original OnRobot power supplies.

Installation

Finally, power up the power supply that will power the Compute Box and the connected Tool(s).

5 Operation

**NOTE:**

It is assumed that the Installation has finished successfully. If not, first do the installation steps in the previous section.

5.1 Overview

OnRobot WebLogic requires to be programmed first with the help of a computer connected to the Compute box. Then it can run standalone without any Ethernet connection.

Steps to program it:

- Setup the Compute Box's Ethernet interface and connect to the Compute Box
- Open the Web Client on your computer to access the WebLogic menu
- Write your program in the WebLogic menu

The following subsections will guide you through these steps.

5.2 Ethernet Interface setup

A proper IP address must be set for the Compute Box and the robot/computer to be able to use the Ethernet interface. There are three ways how it could be configured (using the DIP switch 3 and 4):

- **Auto mode** (factory default)

This is the easiest way of getting the IP addresses to be configured for both the Compute Box and the robot/computer. It is recommended to start with this mode, so this is the factory default setting.

- **Fixed IP mode** (192.168.1.1)

If the **Auto mode** does not work, use this mode to have a fixed IP for the Compute Box. This requires a manual IP address configuration for the robot/computer. (This mode could also be used to reset the IP address to a known value if the Compute Box become unreachable in **Advanced mode**.)

- **Advanced mode** (any static IP/subnet mask)

If the Fixed IP address (192.168.1.1) is already in use in your network or a different subnet needs to be configured, in this mode the IP address and subnet mask can be changed to any value. This also requires a manual IP address configuration for the robot/computer.



NOTE:

To change between modes, first change the DIP switches and then the Compute Box power needs to be cycled for the changes to take effect.

Auto mode



Use the factory default settings (DIP switch 3 and 4 in OFF position).

In this case, the Compute Box has both Dynamic Host Configuration Protocol (DHCP) client, and DHCP server enabled.

DHCP Client enabled means, Compute Box will automatically obtain ("get") IP address FROM the connected robot/computer if that is capable of assigning ("give") IP to the Compute Box.

DHCP Server enabled means, Compute Box will automatically assign ("give") IP address TO the connected robot/computer if that was configured to obtain ("get") IP address automatically.



NOTE:

The assigned IP range is 192.168.1.100-105 (with subnet mask 255.255.255.0).

If the Compute Box is used in a company network where a DHCP server is already in use, it is recommended to disable the DHCP server of the Compute Box by setting DIP switch 4 to the ON position.


If no IP was assigned to the Compute Box within a minute, it will automatically get a fallback IP address (192.168.1.1).



NOTE:

If the Compute Box was in **Advanced mode**, first reset the IP setting by switching to **Fixed IP mode** and then switch back to **Auto mode**.

Fixed IP mode



Set the DIP switch 3 and 4 in ON position and cycle the power for the changes to take effect.

In this case the IP address of the Compute Box is set to 192.168.1.1 (subnet mask is 255.255.255). Both the DHCP Client and Server options are disabled.

Make sure to set the robot/computer IP address manually. To have a proper communication the robot/computer IP address must be in the range of 192.168.1.2 - 192.168.1.254.


Example robot/computer setting:

IP address: 192.168.1.2

Subnet mask: 255.255.255.0

Other settings like Gateway, DNS Server, etc. could be kept empty or set to 0.0.0.0.

Advanced mode



Set the DIP switch 3 in OFF and DIP switch 4 in ON position and cycle the power for the changes to take effect.

In this case the IP address of the Compute Box could be set to any value by using the Web Client. For more details see section **Configuration menu**.

In this mode, the DHCP server option is disabled.

Make sure to have a matching IP setting to your robot/computer network for a proper communication.



NOTE:

If the Compute Box become unreachable (due to improper or forgotten IP settings), switch to **Fixed IP mode** to reset the IP setting.


5.3 Web Client

To access the Web Client on your computer first the Ethernet interface needs to be set up to have a proper communication between your computer and the Compute Box. It is recommended to use Auto mode (for further details see section **Ethernet Interface setup**).

Then do the following steps:

- Connect the Compute Box to your computer with the supplied UTP cable.
- Power the Compute Box with the supplied power supply
- Wait one minute for the Compute Box LED to turn from blue to green.
- Open a web browser on your computer and type in the IP address of the Compute Box (factory default is 192.168.1.1).

The Sign-in page opens:



The screenshot shows the sign-in page for the OnRobot Web Client. The page has a light blue header with the text "Sign in to OnRobot Web Client". Below the header, there are two input fields: "USERNAME" with the value "admin" and "PASSWORD" with a masked password of six dots. There is a "Remember me" checkbox and a "SIGN IN" button. A link for "Forgot your password?" is located below the password field. At the bottom, a grey box contains the text: "Please sign in with the 'admin' username and the default password. You will be prompted to change the default password at first login."


The factory default administrator login is:

Username: admin

Password: OnRobot

Operation

For the first login a new password needs to be entered: (password must be at least 8 characters long)



The screenshot shows a web form titled "Change the default administrator password". It contains two input fields: "NEW PASSWORD" with the placeholder text "Enter your new password here" and "CONFIRM PASSWORD" with the placeholder text "Re-enter your new password here". A "SUBMIT" button is located at the bottom right of the form.

Once logged in you can access top menus. Select **WebLogic** menu.

5.4 OnRobot WebLogic menu

There are two tabs to choose from:

- **Browser** - manage (import/export, etc.) the WebLogic programs
- **Program Editor** - create/edit or run WebLogic programs

In the following these two will be described.

5.4.1 Browser

This tab lists the WebLogic programs that are stored on the Compute Box.

- To create a new program go to the **Program Editor** tab.
- To edit a stored program click on the pencil icon and it will be loaded in the **Program Editor**
- Any program can be deleted by clicking on the trash icon.
- Programs can be exported to your computer by clicking on the down arrow icon.
- Exported programs can be imported with the **Import** button.



NOTE:

The program name that are edited in the **Program Editor** is bolded.

OnRobot WebLogic

This page allows to browse/manage the OnRobot WebLogic programs. You can create new program and run it on the Editor tab. (To make your program run automatically on power-on, leave it running while powering the Compute Box off.)

[Browser](#) [Program Editor](#)

IMPORT You can import a program file from your computer.

PROGRAM NAME	ROWS	SIZE	
Program 1	2	2,742	
Program 2	3	3,609	
Program 3	13	20,480	


5.4.2 Program Editor

This tab shows the currently edited WebLogic program.

WebLogic programs contains 1 or more "rows".

A row contains conditions (blue part) and commands (gray part) like this:


(If) DI1=1 → **(Then)** RG2-Width=77 (force=20N)



(If the robot sets the Digital Input 1 (DI1) of the Compute Box to high, **then** open the RG2 gripper to 77 mm.)


Another row in a program can be like this:

(If) DI1=0 → **(Then)** RG2-Width=20 (force=40N)



(If the robot sets the Digital Input 1 (DI1) of the Compute Box to low, **then** close the RG2 gripper to 20 mm.)

With the above two rows in a program an RG2/6 gripper could be operated (opened and closed) with a single Digital output of a robot, while the opening and closing width and force can be programmed to any value.



To execute a WebLogic program first make sure to enter a program name and click on the **Save** button to store it and then click on the **▶ Run** button.



NOTE:

To make a program run automatically when the Compute Box is powered on just leave the program running while you power the Compute Box off.

To start a new program click on the **New** button.

- To add a new row click on the **Add new conditions and commands.**
- To delete a row click on the icon.
- To move the row up or down click on the icons.



NOTE:

Conditions and commands are executed from the top to the bottom. Same commands at the bottom can override the ones at the top.

- To duplicate a row click on the icon.
- To disable a row (not to be executed) uncheck the checkbox # next to the row number.

The rows must have at least one condition and at least one command to be executed.

Conditions

Conditions are the input fields marked by blue.

There are two types of conditions:

- Digital Input type - like DI4=1
- Device specific value type - like HEX Fx > 10N

These types of conditions can be combined with AND or OR logic to form a more complex condition:

If (DI4=1) OR (HEX Fx > 10 N AND HEX Fx < 20N)

Condition is true if Fx is between 10N and 20N or robot has signaled high in Digital Input 4.

Digital inputs (DI1-DI8) can have the following three states: (click to cycle through the states)


- - Don't care (this bit is masked and will give true result for the bit)
- - give logic true if Input bit is low
- -give logic true if Input bit is high



NOTE:

If no Digital Input type of condition is needed set DI1-DI8 to don't care.

For Device specific values first set the **Select device** by clicking on the arrow icon.



NOTE:

The list contains only the connected devices. If you would like to select a device that is not currently connected check the **Show all devices** checkbox.

For RG2/6, VG10 and Gecko there are three numbers after the device name:

- **0** - If the device is mounted on a Quick Changer or a HEX-E/H QC
- **1** - If the device is mounted on the Primary side of a Dual Quick Changer
- **2** - If the device is mounted on the Secondary side of a Dual Quick Changer




NOTE:

If a Device specific value type condition is not needed set it to -- **Not selected** -- and it will give true result.

Commands

Commands are the input fields marked with gray.

There are two types of commands:



- Device specific value type - like (set RG2 width 77 mm and with force = 20N)
- Digital Output type - like DO4=1

1	2	3	4	5	6	7	8
-	-	-	1	-	-	-	-


 (set Digital Output 4 to logic high)



NOTE:

Both types are always executed so make sure that the not relevant part is always set to Don't change or -- **Not selected** --.

For Device specific value first set the **Select device** by clicking on the arrow icon.



NOTE:

The list contains only the connected devices. If you would like to select a device that is not currently connected check the **Show all devices** checkbox.

For RG2/6, VG10 and Gecko there are three numbers after the device name:

- **0** - If the device is mounted on a Quick Changer or a HEX-E/H QC
- **1** - If the device is mounted on the Primary side of a Dual Quick Changer
- **2** - If the device is mounted on the Secondary side of a Dual Quick Changer

Digital outputs (DO1-DO8) can have the following three states: (click to cycle through the states)

- - Don't change
- - set the Output bit to logic low
- - set the Output bit to logic high

List of Device specific values

Gecko	32
HEX-E/H QC	33
RG2/6	33
RG2-FT	34
VG10	34



NOTE:

Each device has an **OnStart** condition that becomes True only once the device is connected or the program is started and then becomes immediately False. This can be used to detect if a device is connected or set any initial value on program start.

Gecko

Conditions	Description
Preload	Actual force applied to the pads [N] (below 50N it reads 0N)
Ultrasonic	Actual distance measured from the bottom of the gripper to the object.[mm]
Pad position	Actual position of the pads either In or Out
Pads worn	If a Grip was detected and then object distance becomes more than 18mm (without the pads being pulled IN) the object is lost so the Pads are Bad otherwise reads Good .
Busy	Pads are in motion
Grip	While the pads are OUT if the Preload force is reached and the object distance is less than 18mm, then Grip becomes TRUE otherwise FALSE . (resets to FALSE by pulling the pads IN)

Commands	Description
Pad position	To pull the pads In or push the pads Out
Preload threshold	TO set the preload force limit that is used to detect a successful Grip . Available options are: 50N, 90N, 120N

HEX-E/H QC

Conditions	Description
Bias	TRUE if the sensor has been zeroed (biased).
F3D,T3D	$F3D = \sqrt{Fx^2 + Fy^2 + Fz^2}$ [N] $T3D = \sqrt{Tx^2 + Ty^2 + Tz^2}$ [Nm]
Fx, Fy, Fz, Tx, Ty, Tz	Actual force [N] and torque [Nm] values

Commands	Description
Bias	Set to TRUE to zero the F/T sensor signals (not permanent, will revert on power reset)

RG2/6

Conditions	Description
Width	Actual width of the gripper [mm]
Busy	True if the gripper is in motion (can only accept new commands when not busy)
Grip	Internal or external grip is detected.
Safety pressed	True if any of the gripper's safety switch is currently being pressed.
Safety triggered	True if any of the gripper's safety switch is triggered.

Commands	Description
Width	Set the gripper to a new width [mm] with a gripping force [N]
Fingertip offset	Set the fingertip offset from the inner side of the metal [mm]. Positive number means inward.
Power cycle	If safety switch stopped the gripper use this to get back to normal operation. Resets the tool power for a second. If another gripper is connected, that will also be powered off and powered on for a second. (Make sure that during power off no part to will be dropped.)

RG2-FT

Conditions	Description
Proximity (L,R)	Actual values of the left and right fingertip proximity sensors [mm]
Width	Actual width of the gripper [mm]
Busy	True if the gripper is in motion (can only accept new commands when not busy)
Grip	Internal or external grip is detected.
FT Bias	TRUE if the sensor has been zeroed (biased).
Left and Right F3D,T3D	$F3D = \sqrt{F_x^2 + F_y^2 + F_z^2}$ [N] where F_x, F_y, F_z are the fingertip sensor force components $T3D = \sqrt{T_x^2 + T_y^2 + T_z^2}$ [Nm] where T_x, T_y, T_z are the fingertip sensor torque components
Both F3D,T3D	The combined F3D and T3D acting on an object that the gripper gripped on

Commands	Description
Width	Set the gripper to a new width [mm] with a gripping force [N]
Bias	Set to TRUE to zero the F/T sensor signals (not permanent, will revert on power reset)

VG10

Conditions	Description
Actual vacuum A Actual vacuum B	Actual vacuum level [0-80%] for channel A and channel B

Commands	Description
Current limit	Set the current limit (0-1000mA), default is 500mA
Grip	Sets the vacuum level (0-80%) for channel A (param1) and channel B (param2)
Idle	Switch of the motor but keep the valve closed for channel A, B or A+B
Release	Opens the valve to quickly release the vacuum for channel A, B or A+B

6 Additional Software Options

6.1 Compute Box

6.1.1 Interfaces

There are two interface types that could be used:

- **Ethernet interface**

This interface can be used to access the Web Client that can be used to monitor, control, and update the grippers/devices. Furthermore, via this interface the OnRobot WebLogic can also be accessed to program the Digital I/O Interface.

- **Digital I/O interface**

This interface could be used to communicate via simple digital I/O lines with the robots. There are 8 digital input and 8 digital output that could be used. These inputs and outputs can be programmed through the OnRobot WebLogic that requires the Ethernet interface to be used (only for programming time).


6.1.2 Web Client

To access the Web Client on your computer first the Ethernet interface needs to be set up to have a proper communication between your computer and the Compute Box. It is recommended to use Auto mode (for further details see section **Ethernet Interface Setup**).

Then do the following steps:

- Connect the Compute Box to your computer with the supplied UTP cable.
- Power the Compute Box with the supplied power supply
- Wait one minute for the Compute Box LED to turn from blue to green.
- Open a web browser on your computer and type in the IP address of the Compute Box (factory default is 192.168.1.1).

The Sign-in page opens:




The factory default administrator login is:

Username: admin

Password: OnRobot

For the first login a new password needs to be entered: (password must be at least 8 characters long)





Once signed in the following top menus appear:



- **Devices** - Monitor and control the connected devices (e.g.: grippers)
- **Configuration** - Change the Compute Box's settings
- **WebLogic** - Program the Digital I/O interface through OnRobot WebLogic
- **Paths** - Import/export the recorded Paths (not available to all robots)
- **Update** - Update the Compute Box and the devices

Additional Software Options


-  - Account settings (e.g.: change password, add new user)
-  - Select the language of the Web Client

In the following, these menus will be described.

Devices menu


To control/monitor a device click on the **Select** button.

Please select from the detected device(s):




Compute Box

SELECT








HEX-E/H QC

SELECT



RG2

SELECT

	Gecko	38
	HEX-E/H QC	40
	RG2/6.....	41
	RG2-FT.....	43
	VG10	44

Gecko

Gecko Gripper

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

[Monitor and control](#) [Device info](#)

Actual values

Preload force	0 N
Object distance	1.76 mm
Pad position	Pads are out
Part detected	<input checked="" type="checkbox"/>
Busy	<input type="checkbox"/>

[RESET ERRORS](#)


Set values

PAD POSITION

[PADS OUT](#) [PADS IN](#)

PRELOAD THRESHOLD

50 N



There is a force and an ultrasonic distance sensor in the gripper. The actual values of these sensors are:

- **Preload** - the current forces acting on the pads (below 50N it displays 0N)
- **Object distance** - how far the object is from the bottom of the gripper

The state of the gripper could be:

- **Pad position**- Pads are either In or Out (out means ready for gripping)
- **Part detected** - the set preload force limit is reached, and object distance is < 18mm
- **Busy** - the pads are moving

The pads can be controlled by clicking on the **Out** and **In** buttons.

The **Preload threshold** value can be changed if higher preload force is required for a proper grip.

This value is only used to generate a proper **Part detected** signal.



NOTE:

Preload threshold value set on this page is not stored permanently and are restored to the default value (90N) on power reset.

If a part was detected and the object distance becomes $> 18\text{mm}$ (part is lost) BEFORE the pads are set to be IN (normal release) the **Pads worn** warning is displayed in the **Device info** tab.

To reset the warning:

- either click on the **RESET ERRORS** button
- or click on the **Out** button.

HEX-E/H QC

HEX-E/H QC

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

Monitor and control

Device info

Force/Torque values

HEXHC001	
Fx (N)	-0.31
Fy (N)	0.16
Fz (N)	-1.00
Tx (Nm)	-0.008
Ty (Nm)	0.060
Tz (Nm)	0.003

ZERO

The force and torque values (**F_x**,**F_y**,**F_z** and **T_x**,**T_y**,**T_z**) are shown in N/Nm.

The **Zero** toggle switch can be used to zero the force and torque reading.

**NOTE:**

Zero value set on this page is not stored permanently and are restored to the default values on power reset.

RG2/6

RG2

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

[Monitor and control](#)
[Device info](#)

States

Busy
 Grip detected

Safety

RG2 GRIPPER	SWITCH 1	SWITCH 2
Pushed	<input type="radio"/>	<input type="radio"/>
Triggered	<input type="radio"/>	<input type="radio"/>

[POWER CYCLE](#)

Set width and force

FINGERTIP OFFSET

mm [SAVE](#)

WIDTH

51 mm

0 9 18 27 36 45 55 64 73 82 91 100

FORCE

20 N

0 10 20 30 40

Current width: 51 mm

The state of the gripper could be:

- **Busy** - the gripper is moving
- **Grip detected** - the set force limit is reached but the set width is not.

The status of the two safety switch shows:

- **Pushed** - the safety switch 1/2 is still being pushed
- **Triggered** - the safety switch 1/2 has been activated and gripper is stopped.

To recover from a Triggered state:

- Check if any of the safety switch is being pushed
- If yes, remove the object pushing the switch

Additional Software Options

- Click on **Power cycle** to power all devices off and then on to recover.

Fingertip offset must be set according to the current fingertips attached to the gripper. Offset is measured from the inner mating face of the bar metal fingertips. To save the value to the gripper permanently click **Save**.

The gripper can be controlled by adjusting the **Force** and **Width** value. First set the required gripping force and then adjust the width slider that will immediately control the gripper.

RG2-FT

RG2-FT

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

Monitor and control Device info


Force/Torque and Proximity sensor values

LEFT / HEXSC009		HEXSC007 / RIGHT	
98 mm	<input type="range"/>	Proximity	<input type="range"/> 104 mm
-0.01	F_x (N)		0.00
0.06	F_y (N)		-0.09
-0.08	F_z (N)		1.19
0.001	T_x (Nm)		-0.005
0.005	T_y (Nm)		-0.004
0.007	T_z (Nm)		0.001


ZERO

Set width and force

WIDTH



FORCE



Current width: 100 mm

The force and torque values (**F_x,F_y,F_z** and **T_x,T_y,T_z**) are shown in N/Nm along with the Proximity sensor values (optical distance sensor built in the fingertip) are show in mm for the left and right fingertip sensor.

The **Zero** toggle switch can be used to zero the force and torque reading.



NOTE:

Zero value set on this page is not stored permanently and are restored to the default values on power reset.

The gripper can be controlled by adjusting the **Force** and **Width** value. First set the required gripping force and then adjust the width slider that will immediately control the gripper.

VG10

VG10

This page allows the device to be monitored and controlled. By navigating to the Device info tab the device status is shown. (Some functions might not be accessible without Admin permission.)

[Monitor and control](#) [Device info](#)

Actual values

Power limit	500 mA
Channel A	0%
Channel B	0%

Set values

POWER LIMIT

CHANNEL A

CHANNEL B

Lock

The actual vacuum level for **Channel A** and **Channel B** can be seen in percentage (in the range of 0...80% vacuum). The actual value of the **Power limit** is shown in mA.

The **Power limit** can be adjusted in the range of 0...1000mA with the slider.



NOTE:

The power limit set in this page is not stored permanently and always restored to the default value on power reset.

Higher power limit value means the required vacuum level is reached faster (higher airflow), but if it is set too fast overshoot may occur.

Low power limit may not be sufficient for higher percentage of vacuum and the target vacuum level may not be reached.

The **Channel A** and **Channel B** vacuum level can be set individually or in tandem by checking the **Lock** checkbox.


Make sure to set high enough vacuum before you grip and lift any object.


To release the gripped object, click on the **Release** button.

Configuration menu

Configuration

This page allows the configuration of the Compute Box.

**CAUTION**
Incorrect settings may cause the device to lose network connectivity.



1. Digital input mode: NPN
2. Digital output mode: NPN
3. Compute Box IP setting is configured on this page.
4. DHCP server enabled: Compute Box tries to assign IP to the robot.

NETWORK SETTINGS

MAC address	b8:27:eb:0e:c9:a3
Network mode	Static IP
IP address	192.168.1.1
Subnet mask	255.255.255.0

SAVE

ETHERNET/IP SCANNER SETTINGS

IP address to connect to	---
Origin-to-target instance id	1
Target-to-origin instance id	1
Configuration instance id	0
Requested packet interval (ms)	8

SAVE

COMPUTE BOX SETTINGS

Display name	
--------------	--

SAVE

Network settings:

The **MAC address** is a world-wide unique identifier that is fixed for the device.

The **Network mode** drop-down menu can be used to decide if the Compute Box will have a static or a dynamic IP address:

- If it is set to **Dynamic IP**, the Compute Box expects an IP address from a DHCP server. If the network that the device is connected to has no DHCP server, then the fixed 192.168.1.1 IP is used for the device (after 60 seconds of timeout).
- If it is set to **Static IP**, then a fixed IP address and subnet mask must be set.
- If it is set to **Default Static IP**, the fixed IP revert to the factory default and cannot be changed.

After all parameters are set, click on the **Save** button to store the new values permanently. Wait 1 minute and reconnect to the device using the new settings.

Compute Box settings:

In case, more than one Compute Box is used within the same network, for identification purpose any user specific name can be entered to the **Display name**.

EtherNet/IP scanner settings:**NOTE:**

This is a special option of the EtherNet/IP connection for some robots.

In case when the robot is the Adapter and the Compute Box needs to be the Scanner the following addition information is required for the communication:

- **IP address to connect to** - the robot IP address
- **Origin-to-target instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Target-to-origin instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Configuration instance id** - refer to the robot's EtherNet/IP manual (Scanner mode)
- **Requested packet interval (ms)** - RPI value in ms (minimum 4)

Check the checkbox and the Compute Box will try to automatically connect to the robot (via the given IP address).

Paths menu



NOTE:

The Path feature may not be available to your robot type.

This page can be used to import, export, and delete the previously recorded paths. In this way a Path can be copied to a different Compute Box.

Manage paths

This page allows uploading and downloading path files.

IMPORT You can import a path file from your computer.

PATH NAME	SIZE (IN BYTES)		
1539	1,692	↓	🗑️
3923	1,972	↓	🗑️
3924	1,972	↓	🗑️

To import a previously exported Path (.ofp file) click on **Import** and browse for the file.

The available Paths are listed at the end of the page. Any paths can be exported and downloaded as a .ofp file or permanently deleted to free up the list if a path is not needed anymore.



NOTE:


Always make sure that you do not delete any path that is currently in use in any of your robot programs. Otherwise the path will need to be re-recorded, since the delete operation cannot be undone.

The Compute Box can store up to 100 Mbytes of paths that is roughly equal to 1000 hours of recordings.

Update menu

Start the software update by clicking on the **Browse** button to browse for the .cbu software update file. Then the **Browse** button will turn to **Update**.


Click on that **Update** button to start the software update process:



CAUTION:

During the update process (takes about 5-10 minutes) **DO NOT** unplug any device or close the browser window. Otherwise the Compute Box could be damaged.

If the software update is finished and was successful, the following message is shown:



Now disconnect the device and use it as usual.




NOTE:

If the software update failed, please contact your distributor.

 **Account settings**

This menu can be used to:

- See the currently sign-id user
- Go to **Account settings**
- Sign-out




Account settings:


This page has two tabs:

- **My profile** - to see and update the currently logged in users profile (e.g.: change password)
- **Users** - to manage users (e.g.: add/remove/edit)

On the **My profile** tab to change any profile data (e.g.: password) click on the **Update profile** button.



On the **Users** tab click on the **Add new user** button to add more users:



The screenshot shows a modal window titled "Add new user" with a close button (X) in the top right corner. The form contains the following fields and controls:


- USERNAME:** A text input field with the placeholder text "Enter username here".
- FIRST NAME:** A text input field.
- LAST NAME:** A text input field.
- E-MAIL:** A text input field.
- PHONE:** A text input field.
- ROLE:** A dropdown menu with "User" selected.
- STATUS:** A checkbox labeled "Active" which is checked.
- DESCRIPTION:** A large text area for additional information.
- PASSWORD:** A text input field with the placeholder text "Enter user's password here".
- CONFIRM PASSWORD:** A text input field with the placeholder text "Re-enter password here".


At the bottom of the form are two buttons: "SAVE" and "CANCEL".

There are three user levels:

- Administrator
- Operator
- User

Fill in the user information and click **Save**.

Later on to change any user information just click on the edit  icon.



To prevent a user to sign-in either could be:

- deactivated by changing its **Active** status in the edit mode
- or removed by clicking the delete icon.

6.2 Modbus TCP

MODBUS TCP uses Ethernet as the physical layer, otherwise it is very similar to Modbus RTU. For further details on the protocol, please refer to modbus.org’s MODBUS Application Protocol Specification (http://www.modbus.org/docs/Modbus_Application_Protocol_V1_1b3.pdf).



NOTE:

In this section the address and register values are written in the following format:

- DD (HH) where the DD is in decimal and the HH is in hexadecimal format.

6.2.1 Settings

The table below shows the required settings to be used when communicating with the OnRobot's products over MODBUS TCP.

Settings	
Modbus TCP server IP address	Compute Box IP address (default is 192.168.1.1)
Port number	502
Number of concurrent connections	1

For the Gecko gripper, RG2, RG6 and VG10 the Device address depends only on the mounting option and not on the gripper type:

	via Quick Changer	via HEX-E/H QC	via Dual Quick Changer
Device address	65 (0x41)	65 (0x41)	Primary side (1) - 66 (0x42) Secondary side (2) - 67 (0x43)

For HEX-E/H QC and RG2-FT the Device address is fixed:

	HEX-E/H QC	RG2-FT
Device address	64 (0x40)	65 (0x41)

For the Compute Box the Device address is fixed (it has only one functionality to reset the tool power):

	Compute Box
Device address	63 (0x3F)

6.2.2 Function codes

OnRobot products currently support the function codes listed below. The products will respond with an appropriate exception code, if the function is not executed correctly. Please refer to MODBUS Application Protocol page 48 for detailed description of the different exception codes. Note that the product will provide no response if the settings are not correct.

3 (0x03) Read Holding Registers

Use this function code to read out one or multiple consecutive registers. Please refer to MODBUS Application Protocol page 15 for frame and response details.

6 (0x06) Write Single Register

Use this function code to set the value of a single register. Please refer to MODBUS Application Protocol page 19 for frame and response details.

16 (0x10) Write Multiple Registers

Use this function code to set the values of multiple consecutive registers. Please refer to MODBUS Application Protocol page 19 for frame and response details.

23 (0x17) Read/Write Multiple Registers

Use this function code to set the values and read out one or multiple consecutive registers. Note that the registers to be set are set before the registers to be read are read. Please refer to MODBUS Application Protocol page 38 for frame and response details.

6.2.3 Registers

📖	Gecko	53
📖	HEX-E/H QC	55
📖	RG2	56
📖	RG6	56
📖	RG2-FT	58
📖	VG10	61
📖	Compute Box	62

Gecko

The table below provides an overview of the available MODBUS registers in the Gecko Gripper.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.

Address	Register	Access
0	0x0000 Pad Control	Read + Write
4	0x0004 Preload force threshold	Read + Write
256	0x0100 Part detected	Read only
257	0x0101 Pads worn	Read only
260	0x0104 Busy	Read only
261	0x0105 Actual preload force	Read only
262	0x0106 Actual ultrasonic range	Read only
263	0x0107 Pad position	Read only

0 (0x0000) Pad Control (Read + Write)

Controls the pad position.

Value	Description
0x0000	Pull Pads IN
0x0001	Push Pads OUT

4 (0x0004) Preload force threshold (Read + Write)

Sets the threshold for the preload force signal (Preloaded). Available options are:

Value	Description
0x0000	50N
0x0001	90N
0x0002	120N (default)

256 (0x0100) Part detected (Read only)

Reads high (0x0001) when the pads are OUT, the preset preload force has been reached and the Actual ultrasonic range is lower than 18mm, otherwise low (0x0000). It is cleared when the pads are pulled IN.

257 (0x0101) Pads worn (Read only)

Reads high (0x0001) when the pads need to be replaced.

260 (0x0104) Busy (Read only)

Reads high (0x0001) when pads are in motion otherwise reads low (0x0000).

261 (0x0105) Actual preload force (Read only)

Reads the actual preload force in 1/100 N.

262 (0x0106) Actual ultrasonic range (Read only)

Reads the actual preload force in 1/100 mm.

263 (0x0107) Pad position (Read only)

Reads the actual position of the pads:

Value	Description
0x0000	Pads IN
0x0001	Pads OUT

HEX-E/H QC

The table below provides an overview of the available MODBUS registers in the HEX-E/H QC.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.

Address	Register	Access	
0	0x0000	Zero	Read + Write
257	0x0101	Status	Read only
259	0x0103	Fx	Read only
260	0x0104	Fy	Read only
261	0x0105	Fz	Read only
262	0x0106	Tx	Read only
263	0x0107	Ty	Read only
264	0x0108	Tz	Read only

0 (0x0000) Bias (Read + Write)

Zero the force and torque values to cancel any offset.

Value	Description
0x0000	Un-Zero
0x0001	Zero

256 (0x0100) Status (Read only)

Reads low (0x0000) when there is no error.

259 (0x0103) Fx (Read only)

Force value along the X axis (in the sensor coordinate system) in 1/10 N. The value is signed INT.

260 (0x0104) Fy (Read only)

Force value along the Y axis (in the sensor coordinate system) in 1/10 N. The value is signed INT.

261 (0x0105) Fz (Read only)

Force value along the Z axis (in the sensor coordinate system) in 1/10 N. The value is signed INT.

262 (0x0106) Tx (Read only)

Torque value about the X axis (in the sensor coordinate system) in 1/100 Nm. The value is signed INT.

263 (0x0107) Ty (Read only)

Torque value about the Y axis (in the sensor coordinate system) in 1/100 Nm. The value is signed INT.

264 (0x0108) Tz (Read only)

Torque value about the Z axis (in the sensor coordinate system) in 1/100 Nm. The value is signed INT.

RG2
RG6

The table below provides an overview of the available MODBUS registers in the RG2/6.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.

Address		Register	Access
0	0x0000	Target force	Write
1	0x0001	Target width	Write
2	0x0002	Control	Write
258	0x0102	Fingertip offset	Read only
263	0x0107	Actual depth	Read only
264	0x0108	Actual relative depth	Read only
267	0x010B	Actual width	Read only
268	0x010C	Status	Read only
275	0x0113	Actual width with offset	Read only
1031	0x0407	Set Fingertip offset	Write only

0 (0x0000) Target force (Write)

This field sets the target force to be reached when gripping and holding a workpiece. It must be provided in 1/10th Newtons. The valid range is 0 to 400 for the RG2 and 0 to 1200 for the RG6.

1 (0x0001) Target width (Write)

This field sets the target width between the finger to be moved to and maintained. It must be provided in 1/10th millimeters. The valid range is 0 to 1100 for the RG2 and 0 to 1600 for the RG6. Please note that the target width should be provided corrected for any fingertip offset, as it is measured between the insides of the aluminum fingers.

2 (0x0002) Control (Write)

The control field is used to start and stop gripper motion. Only one option should be set at a time. Please note that the gripper will not start a new motion before the one currently being executed is done (see busy flag in the Status field). The valid flags are:

Value	Name	Description
1 (0x0001)	grip	Start the motion, with the preset target force and width. Width is calculated without the fingertip offset. Please note that the gripper will ignore this command if the busy flag is set in the status field.
8 (0x0008)	stop	Stop the current motion.
16 (0x0010)	grip_w_offset	Same as grip, but width is calculated with the set fingertip offset.

258 (0x0102) Fingertip offset (Read only)

Indicates the current fingertip offset in 1/10 millimeters. Please note that the value is a signed two's complement number.

263 (0x0107) Actual depth (Read only)

Indicates the current depth of the gripper, to be used for depth compensation. The depth is relative to the fully closed position, provided in 1/10 millimeters. Please note that the value is a signed two’s complement number.

264 (0x0108) Actual relative depth (Read only)

Indicates the current depth of the gripper, to be used for depth compensation. The depth is relative to the position at which the latest motion was initiated and is provided in 1/10 millimeters. Please note that the value is a signed two’s complement number.

267 (0x010B) Actual width (Read only)

Indicates the current width between the gripper fingers in 1/10 millimeters. Please note that the width is provided without any fingertip offset, as it is measured between the insides of the aluminum fingers.

268 (0x010C) Status (Read only)

This status field indicates the status of the gripper and its motion. It is composed of 7 flags, described in the table below.

Bit	Name	Description
0 (LSB)	busy	High (1) when a motion is ongoing, low (0) when not. The gripper will only accept new commands when this flag is low.
1	grip detected	High (1) when an internal- or external grip is detected.
2	S1 pushed	High (1) when safety switch 1 is pushed.
3	S1 triggered	High (1) when safety circuit 1 is activated. The gripper will not move while this flag is high; can only be reset by power cycling the gripper.
4	S2 pushed	High (1) when safety switch 2 is pushed.
5	S2 triggered	High (1) when safety circuit 2 is activated. The gripper will not move while this flag is high; can only be reset by power cycling the gripper.
6	Safety error	High (1) when on power on any of the safety switch is pushed.
10-16	Reserved	Not used

275 (0x0113) Actual width with offset (Read only)

Indicates the current width between the gripper fingers in 1/10 millimeters. The set fingertip offset is considered.

1031 (0x0407) Set Fingertip offset (Write only)

This field sets the Fingertip offset in 1/10 mm. Positive number means an inward offset (decreases how much the gripper can be closed).

RG2-FT

The table below provides an overview of the available MODBUS registers in the RG2-FT.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.

Address	Register	Access	
0	0x0000	Zero	Read + Write
2	0x0002	Target force	Write
3	0x0003	Target width	Write
4	0x0004	Control	Write
5	0x0005	Proximity Offset (L)	Read + Write
6	0x0006	Proximity Offset (R)	Read + Write
257	0x0101	Status (L)	Read only
259	0x0103	Fx (L)	Read only
260	0x0104	Fy (L)	Read only
261	0x0105	Fz (L)	Read only
262	0x0106	Tx (L)	Read only
263	0x0107	Ty (L)	Read only
264	0x0108	Tz (L)	Read only
266	0x010A	Status (L)	Read only
268	0x010C	Fx (L)	Read only
269	0x010D	Fy (L)	Read only
270	0x010E	Fz (L)	Read only
271	0x010F	Tx (L)	Read only
272	0x0110	Ty (L)	Read only
273	0x0111	Tz (L)	Read only
274	0x0112	Proximity Status (L)	Read only
275	0x0113	Proximity Value (L)	Read only
277	0x0115	Proximity Status (R)	Read only
278	0x0116	Proximity Value (R)	Read only
280	0x0118	Actual gripper width	Read only
281	0x0119	Gripper Busy	Read only
282	0x011A	Grip detected	Read only

0 (0x0000) Bias (Read + Write)

Zero the force and torque values to cancel any offset.

Value	Description
0x0000	Un-Zero
0x0001	Zero

2 (0x0002) Target force (Write)

This field sets the target force to be reached when gripping and holding a workpiece. It must be provided in 1/10 Newtons. The valid range is 0 to 400.

3 (0x0003) Target width (Write)

This field sets the target width between the finger to be moved to and maintained. It must be provided in 1/10th millimeters. The valid range is 0 to 1000. Please note that the target width should be provided corrected for any fingertip offset, as it is measured between the insides of the aluminum fingers.

4 (0x0004) Control (Write)

The control field is used to start and stop gripper motion. Only one bit should be set at a time. Please note that the gripper will not start a new motion before the one currently being executed is done (see busy flag in the Status field). The valid flags are:

Value	Name	Description
0x0000	stop	Stop the current motion.
0x0001	grip	Start the motion, with the preset target force and width. Please note that the gripper will ignore this flag if the busy flag is set in the status field.

5 (0x0005) Proximity Offset L (Read + Write)

This field sets the offset of the left proximity sensor that is subtracted from the raw signal. It must be provided in 1/10 millimeters.

6 (0x0006) Proximity Offset R (Read + Write)

Same as the left above.

256 (0x0100) Status (L) (Read only)

Reads low (0x0000) when there is no error with the left finger sensor.

259 (0x0103) Fx (L) (Read only)

Left finger sensor's force value along the X axis (in the sensor coordinate system) in 1/10N. The value is signed INT.

260 (0x0104) Fy (L) (Read only)

Left finger sensor's force value along the Y axis (in the sensor coordinate system) in 1/10N. The value is signed INT.

261 (0x0105) Fz (L) (Read only)

Left finger sensor's force value along the Z axis (in the sensor coordinate system) in 1/10N. The value is signed INT.

262 (0x0106) Tx (L) (Read only)

Left finger sensor's torque value about the X axis (in the sensor coordinate system) in 1/100 Nm. The value is signed INT.

263 (0x0107) Ty (L) (Read only)

Left finger sensor's torque value about the Y axis (in the sensor coordinate system) in 1/100 Nm. The value is signed INT.

264 (0x0108) Tz (L) (Read only)

Left finger sensor's torque value about the Z axis (in the sensor coordinate system) in 1/100 Nm. The value is signed int.

266 (0x010A) Status (R) (Read only)

Same as the left above.

268 (0x010C) Fx (R) (Read only)

Same as the left above.

269 (0x010D) Fy (R) (Read only)

Same as the left above.

270 (0x010E) Fz (R) (Read only)

Same as the left above.

271 (0x010F) Tx (R) (Read only)

Same as the left above.

272 (0x0110) Ty (R) (Read only)

Same as the left above.

273 (0x0111) Tz (R) (Read only)

Same as the left above.

274 (0x0112) Proximity Status (L) (Read only)

Reads low (0x0000) when there is no error with the left proximity sensor.

275 (0x0113) Proximity Value (L) (Read only)

Reads the current distance from the left proximity sensor in 1/10 mm. The value is signed INT.

277 (0x0115) Proximity Status (R) (Read only)

Same as the left above.

278 (0x0116) Proximity Value (R) (Read only)

Same as the left above.

280 (0x0118) Actual gripper width (Read only)

Indicates the current width between the gripper fingers in 1/10 millimeters. Please note that the width is provided without any fingertip offset, as it is measured between the insides of the aluminum fingers.

281 (0x0119) Gripper busy (Read only)

High (1) when a motion is ongoing, low (0) when not. The gripper will only accept new commands when this flag is low.

282 (0x011A) Grip detected (Read only)

High (1) when an internal- or external grip is detected.

VG10

The table below provides an overview of the available MODBUS registers in the VG10.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.

Address	Register	Access	
0	0x0000	Channel A Control	Read + Write
1	0x0001	Channel B Control	Read + Write
2	0x0002	Current limit	Read + Write
258	0x0102	Channel A actual vacuum	Read only
259	0x0103	Channel B actual vacuum	Read only

0 (0x0000) Channel A Control (Read + Write)

This register allows for control of channel A. The register is split into two 8-bit fields:

Bits 15-8	Bits 7-0
Control mode	Target vacuum

The Control mode field must contain one of these three values:

Value	Name	Description
0 (0x00)	Release	Commands the channel to release any work item and stop the pump, if not required by the other channel.
1 (0x01)	Grip	Commands the channel to build up and maintain vacuum on this channel.
2 (0x02)	Idle	Commands the channel to neither release nor grip. Workpieces may "stick" to the channel if physically pressed towards its vacuum cups, but the VG10 will use slightly less power.

The Target vacuum field sets the level of vacuum to be build up and maintained by the channel. It is used only when the control mode is 1 (0x01) / Grip. The target vacuum should be provided in % vacuum. It should never exceed 80.

Examples:

Setting the register value 0 (0x0000) will command the VG10 to release the work item.

Setting the register value 276 (0x0114) will command the VG10 to grip at 20 % vacuum.

Setting the register value 296 (0x0128) will command the VG10 to grip at 40 % vacuum.

Setting the register value 331 (0x014B) will command the VG10 to grip at 75 % vacuum.

Setting the register value 512 (0x0200) will command the VG10 to idle the channel.

1 (0x0001) Channel B Control (Read + Write)

Same as in channel A above.

2 (0x0002) Current limit (Read + Write)

Set and read the current limit. The limit is provided and must be given in mA (milli-amperes). The limit is 500mA per default and should never be set above 1000 mA.

258 (0x0102) Channel A actual vacuum (Read only)

Reads the actual vacuum on Channel A. The vacuum is provided in (1/1000 of relative vacuum. Please note that this differs from the setpoint given in percent, as extra accuracy is desirable on the actual vacuum.

259 (0x0103) Channel B actual vacuum (Read only)

Same as in channel A above.

Compute Box

The table below provides an overview of the available MODBUS registers for the Compute Box.

All writable registers can be accessed using function codes 6, 16 or 23 and all readable registers can be accessed using function codes 3 or 23.












Address		Register	Access
0	0x0000	Reset tool power	Write

0 (0x0000) Reset tool power (Write)

Writing 2 to this field powers the tool off for a short amount of time and then powers them back. This can be used to reset the RG2 or RG6 after the safety switch is triggered. It could take 1-2 seconds.

7 Hardware Specification

7.1 Technical sheets

 Gecko	64
 HEX-E QC	67
 HEX-H QC.....	69
 Quick Changer	71
 Quick Changer for I/O	71
 Dual Quick Changer.....	71
 Quick Changer - Tool side	71
 RG2-FT.....	73
 RG2	78
 RG6	81
 VG10	84

Gecko

General Properties					Unit
Gripper					
Workpiece Material	Polished Steel	Acrylic	Glass	Sheet Metal	
Maximum payload (x2 safety factor)	6.5 14.3	6.5 14.3	5.5 12.1	5.5 12.1	[kg] [lb]
Preload required for max adhesion	140				[N]
Detachment time	300				[msec]
Holds workpiece on power loss?	yes				
Pads					
Change-out interval	150 000 to 200 000 cycles for HIGH preload 200 000 to 250 000 cycles for LOW preload				[cycles]
Manual Cleaning	Isopropyl alcohol and lint free cloth				
Robotic cleaning system	Cleaning Station				
Robotic cleaning interval and % recovery	Refer to Cleaning Station User Guide				
Sensors					
	Pre-load sensor		Ultrasonic Range sensor		
Range	45 [N] 9 [lb]	140 [N] 31 [lb]	0	260 [mm] 10 [inch]	[N][mm] [lb][inch]
Error	7%		2%		
IP Classification	42				
Dimensions (HxW)	187 x 146 7.3 x 5.7				[mm] [inch]
Weight	2.85 6.3				[kg] [lb]



NOTE:

Avoid preloading the gripper with an inverted robot or in non-vertical loading conditions. If preloaded whilst inverted, preload sensor will not meet typical performance standards.

Operating Conditions	Minimum	Typical	Maximum	Unit
Temperature	0 32	- -	50 122	[°C] [°F]
Surface Characteristics*	Matte finish	Highly polished	-	

* Smoother surfaces require less preload force for a desired payload force.

Specification or Feature	Target value
Parts Presence Sensing	Yes (Ultrasonic)
Pad Material	Proprietary silicone blend
Wear Properties	Depends on surface roughness and preload
Pad Attachment Mechanism	Magnetic
Change-out interval	150000 – 200000 for HIGH PRELOAD 200000 – 250000 for LOW PRELOAD
Cleaning system	Cleaning station
Cleaning interval and % recovery	See Cleaning Station Manual

Effectiveness on Different Materials

The Gecko Gripper is best suited for smooth, low surface roughness substrates that are generally flat, stiff, and rigid. For other materials, the Gecko Gripper’s effectiveness drops depending the stiffness and roughness of the picking surface. The table below shows a relationship between rigid and flexible substrates, surface finish, payload and the required preload to pick up said substrate. For example, if the customer knows that their part/substrate is rigid, with a mirror-like finish and weighs 2kg, the preload required to pick up the part/substrate is a medium-level preload.

Flexibility	Surface finish	Payload (kg)	Required Preload
Rigid	Mirror-like finish	0 to 2	Low
		2 to 4	Medium
		4 to 6	High
	Smooth	0 to 2	Medium
		2 to 4	High
		4 to 6	N/A
	Matte	0 to 2	High
		2 to 4	N/A
		4 to 6	N/A
Flexible	Mirror-like finish	0 to 2	Medium
		2 to 4	High
		4 to 6	N/A
	Smooth	0 to 2	High
		2 to 4	N/A
		4 to 6	N/A
	Matte	0 to 2	N/A
		2 to 4	N/A
		4 to 6	N/A

To further elaborate the significance between preload and payload, the table below shows visual matrix that displays the capability of the gecko gripper to pick up different materials with varying stiffness and roughness, at three different preload values (low 40N, medium 90N, high 140N).

Stiffness	Roughness	Example of material	Preload - 140N						Preload - 90N						Preload - 40N					
			Payload [kg]						Payload [kg]						Payload [kg]					
			0.1	0.5	1	2	4	6	0.1	0.5	1	2	4	6	0.1	0.5	1	2	4	6
1	1	Mylar	✓	✓	*				✓	*				✓	*					
5	1	Transparency sheet	✓	✓	*	*			✓	*				✓	*					
10	1	Polished mirror-like steel, solar panel	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	*	✓	✓	✓	*			
1	5	Cling film, ziploc bags	✓	✓					✓	*				✓	✓					
5	5	Glossy cardboard (cereal box)	✓	✓					✓	*				✓	*					
10	5	Printed circuit board	✓	✓	✓	✓			✓	✓	*			✓	*					
1	10	Laminating plastic / film																		
5	10	Corrugated cardboard																		
10	10	Sandblasted aluminum																		

✓ the gripper can easily pick up the material

* the gripper can pick up the material in some cases (requires caution and testing to verify)

Nothing the gripper cannot pick up this type of material.



NOTE:

This table is to be utilized as a guide to better understand the payload capacity and substrate type for the Gecko Gripper.

The criteria for stiffness and roughness is a basic scale from 1-10, here are the benchmarks used to determine the values.

Stiffness	Description	Example
1	Flexible	Fabric
5	Semi-flexible	Cardboard
10	Stiff	Metal

Roughness	Description	Example	RMS Value
1	Polished/Smooth	Polished Metal	0.1 micron
5	Textured	Cardboard	7 microns
10	Rough	Sandblasted Metal	28 microns

HEX-E QC

General Properties	6-Axis Force/Torque Sensor				Unit
	Fxy	Fz	Txy	Tz	
Nominal Capacity (N.C)	200	200	10	6.5	[N] [Nm]
Single axis deformation at N.C (typical)	± 1.7 ± 0.067	± 0.3 ± 0.011	± 2.5 ± 2.5	± 5 ± 5	[mm] [°] [inch] [°]
Single axis overload	500	500	500	500	[%]
Signal noise* (typical)	0.035	0.15	0.002	0.001	[N] [Nm]
Noise-free resolution (typical)	0.2	0.8	0.01	0.002	[N] [Nm]
Full scale nonlinearity	< 2	< 2	< 2	< 2	[%]
Hysteresis (measured on Fz axis , typical)	< 2	< 2	< 2	< 2	[%]
Crosstalk (typical)	< 5	< 5	< 5	< 5	[%]
IP Classification	67				
Dimensions (H x W x L)	50 x 71 x 93 1.97 x 2.79 x 3.66				[mm] [inch]
Weight (with built-in adapter plates)	0.347 0.76				[kg] [lb]

* Signal noise is defined as the standard deviation (1 σ) of a typical one second no-load signal.



Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	7	-	24	[V]
Power consumption	-	-	0.8	[W]
Operating temperature	0 32	- -	55 131	[°C] [°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[Hours]

Complex loading

During single-axis loading, the sensor can be operated up to its nominal capacity. Above the nominal capacity the reading is inaccurate and invalid.

During complex loading (when more than one axis is loaded) the nominal capacities are reduced. The following diagrams show the complex loading scenarios.

The sensor cannot be operated outside of the Normal Operating Area.



HEX-H QC

General Properties	6-Axis Force/Torque Sensor				Unit
	Fxy	Fz	Txy	Tz	
Nominal Capacity (N.C)	200	200	20	13	[N] [Nm]
Single axis deformation at N.C (typical)	± 0.6 ± 0.023	± 0.25 ± 0.009	± 2 ± 2	± 3.5 ± 3.5	[mm] [°] [inch] [°]
Single axis overload	500	400	300	300	[%]
Signal noise* (typical)	0.1	0.2	0.006	0.002	[N] [Nm]
Noise-free resolution (typical)	0.5	1	0.036	0.008	[N] [Nm]
Full scale nonlinearity	< 2	< 2	< 2	< 2	[%]
Hysteresis (measured on Fz axis , typical)	< 2	< 2	< 2	< 2	[%]
Crosstalk (typical)	< 5	< 5	< 5	< 5	[%]
IP Classification	67				
Dimensions (H x W x L)	50 x 71 x 93 1.97 x 2.79 x 3.66				[mm] [inch]
Weight (with built-in adapter plates)	0.35 0.77				[kg] [lb]

* Signal noise is defined as the standard deviation (1 σ) of a typical one second no-load signal.



Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	7	-	24	[V]
Power consumption	-	-	0.8	[W]
Operating temperature	0 32	- -	55 131	[°C] [°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[Hours]

Complex loading

During single-axis loading, the sensor can be operated up to its nominal capacity. Above the nominal capacity the reading is inaccurate and invalid.

During complex loading (when more than one axis is loaded) the nominal capacities are reduced. The following diagrams show the complex loading scenarios.

The sensor cannot be operated outside of the Normal Operating Area.



- Quick Changer
- Quick Changer for I/O
- Dual Quick Changer
- Quick Changer - Tool side


If not specified, the data represent the combination of the different Quick Changer types/sides.

Technical data	Min	Typical	Max	Units
Permissible force*	-	-	400*	[N]
Permissible torque*	-	-	50*	[Nm]
Rated payload*	-	-	20* 44	[kg] [lbs]
Repeatability	-	-	±0.02	[mm]
IP Classification	64			
Operating life (Tool change)	-	5.000	-	[cycles]
Operating life (Robot operation)	10	-	-	[M cycles]





* See load capacity graph on the next page.

	Quick Changer	Quick Changer for I/O	Dual Quick Changer	Quick Changer - Tool Side	Units
Weight	0.06	0.093	0.41	0.14	[kg]
	13.22	2.05	90.39	30.86	[lb]
Dimensions	See Mechanical dimension section				[mm] [inch]

Load capacity



RG2-FT

General Properties	Min	Typical	Max	Units
Payload Force Fit   2 Kg	-	-	2	[kg]
Payload Form Fit   4 Kg	-	-	4	[Kg]
	-	-	8.8	[lb]
Total stroke (adjustable)	0	-	100	[mm]
	0	-	3.93	[inch]
Finger position resolution	-	0.1	-	[mm]
	-	0.004	-	[inch]
Repetition accuracy	-	0.1	0.2	[mm]
	-	0.004	0.007	[inch]
Reversing backlash	0.2	0.4	0.6	[mm]
	0.007	0.015	0.023	[inch]
Gripping force (adjustable)	3	-	40	[N]
Gripping speed*	55	110	184	[mm/s]
Gripping time**	0.04	0.07	0.11	[s]
Ambient operating temperature	5	-	50	[°C]
Storage temperature	0	-	60	[°C]
Motor	Integrated, electric BLDC			
IP Classification	IP54			
Dimensions	219 x 149 x 49			[mm]
	8.6 x 5.9 x 1.9			[inch]
Product weight	0.98			[kg]
	2.16			[lb]

* see speed table 75

** based on 8mm total movement between fingers. The speed is linearly proportional to the force. For more details see speed table on page 75.


Force Sensor Properties	Fxy	Fz	Txy	Tz	Units
Nominal capacity (N.C.)	20	40	0.7	0.5	[N] [Nm]
Single axis overload	200	200	200	200	[%]
Noise free resolution	0.1	0.4	0.008	0.005	[N] [Nm]
Single axis deformation at N.C.	0.4	0.1	2	5	[mm] [°]
	0.015	0.04			[inch] [°]
Full scale nonlinearity	< 2				[%]
Temperature compensation					

Proximity Sensor Properties	Min	Typical	Max	Units
Sensing range	0	-	100	[mm]
	0	-	3.93	[inch]
Precision	-	2	-	[mm]
	-	0.078	-	[inch]
Non-linearity*	-	12	-	[%]


* the non-linearity refers to the max value and depends on the object properties (e.g. surface type and color)

Operating Conditions	Minimum	Typical	Maximum	Unit
Power requirement (PELV)	24	-	24	[V]
Power consumption	6.5	-	22	[W]
Operating temperature	0	-	55	[°C]
	32	-	131	[°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[Hours]


Proximity sensor* typical accuracy



RG2-FT Gripping Speed Graph





Gripper Working Range





The dimensions are in millimeters.

Fingertips

The standard fingertips can be used for many different workpieces. If custom fingertips are required, they can be made to fit the Gripper fingers.



SECTION G-G



Dimensions of the Gripper's finger, in millimeters.



NOTE:

During the fingertip design, the following shall be considered to maintain optimal performance:

Clear optical path for the proximity sensors

Protect the proximity sensors from direct sunlight or strong light source

Avoid dust and liquid penetration



WARNING:

The proximity sensors are sensitive parts and shall be protected against:

Direct strong light (such as directional laser sources)

Direct high temperature

Mechanical contacts in any case

Expose to any liquid or fine conductive dust





NOTE:

Please clean regularly the proximity sensor surface with low pressure compressed air (<5 bar) from a 5 cm distance. For stronger contamination use isopropyl alcohol with a soft cotton swab to keep it clean.

Finger Thickness

The default fingertips are considered while the finger thickness has been set and could not be changed in the software. In case when custom fingertips are used, the user should manually compensate for the difference in the finger thickness.

RG2

General Properties	Minimum	Typical	Maximum	Unit
Payload Force Fit   2 Kg 5 Kg	-	-	2 4.4	[kg] [lb]
Payload Form Fit	-	-	5 11	[kg] [lb]
Total stroke (adjustable)	0 0	- -	110 4.33	[mm] [inch]
Finger position resolution	- -	0.1 0.004	- -	[mm] [inch]
Repetition accuracy	- -	0.1 0.004	0.2 0.007	[mm] [inch]
Reversing backlash	0.1 0.004	- -	0.3 0.011	[mm] [inch]
Gripping force (adjustable)	3	-	40	[N]
Gripping force deviation		±25		%
Gripping speed*	38	-	127	[mm/s]
Gripping time**	0.06	-	0.21	[s]
Storage temperature	0 32	- -	60 122	[°C] [°F]
Motor	Integrated, electric BLDC			
IP Classification	IP54			
Dimensions	213 x 149 x 36 8.3 x 5.9 x 1.4			[mm] [inch]
Weight	0.78 1.72			[kg] [lb]


*See table on the next page

** based on 8mm total movement between fingers. The speed is linearly proportional to the force. For more details see speed table on next page.


Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	20	24	25	[V]
Current consumption	70	-	600*	[mA]
Operating temperature	5 41	- -	50 122	[°C] [°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[Hours]

*Current spikes up to 3A (max 6mS) may occur during the release action.


RG2 Gripping Speed Graph



RG2 Work Range




Gripping on long objects can unintentionally activate the Safety switches. The maximum workpiece height (calculated from the end of the fingertips) is dependent on the gripping width (w). For various width values the height (h) limit is given below:





Fingertips

The standard fingertips can be used for many different workpieces. If custom fingertips are required, they can be made to fit the Gripper's fingers according to the dimensions (mm) shown below:



RG6

General Properties	Minimum	Typical	Maximum	Unit
Payload Force Fit 	-	-	6 13.2	[kg] [lb]
Payload Form Fit 	-	-	10 22.04	[Kg] [lb]
Total stroke (adjustable)	0	-	160 6.3	[mm] [inch]
Finger position resolution	-	0.1 0.004	-	[mm] [inch]
Repetition accuracy	-	0.1 0.004	0.2 0.007	[mm] [inch]
Reversing backlash	0.1 0.004	-	0.3 0.011	[mm] [inch]
Gripping force (adjustable)	25	-	120	[N]
Gripping force deviation		±25		%
Gripping speed*	51	-	160	[mm/s]
Gripping time**	0.05	-	0.15	
Storage temperature	0 32		60 122	[°C] [°F]
Motor	Integrated, electric BLDC			
IP Classification	54			
Dimensions	262 x 212 x 42 10.3 x 8.3 x 1.6			[mm] [inch]
Weight	1.25 2.76			[kg] [lb]


*See table on the next page

** based on 8mm total movement between fingers. The speed is linearly proportional to the force. For more details see speed table on next page.


Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	20	24	25	[V]
Current consumption	70	-	600*	[mA]
Operating temperature	5 41	-	50 122	[°C] [°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[Hours]

*Current spikes up to 3A (max 6mS) may occur during the release action.


RG6 Gripping Speed Graph



RG6 Work Range




Gripping on long objects can unintentionally activate the Safety switches. The maximum workpiece height (calculated from the end of the fingertips) is dependent on the gripping width (w). For various width values the height (h) limit is given below:



Fingertips

The standard fingertips can be used for many different workpieces. If custom fingertips are required, they can be made to fit the Gripper's fingers according to the dimensions (mm) shown below:



VG10


General Properties		Minimum	Typical	Maximum	Unit
Vacuum		5 % -0.05 1.5	- - -	80 % -0.810 24	[Vacuum] [Bar] [inHg]
Air flow		0	-	12	[NI/min]
Arms adjustment		0	-	270	[°]
Arm holding torque		-	6	-	[Nm]
Payload	Rated	10 22			[kg] [lb]
	Maximum	15 33			[kg] [lb]
Vacuum cups		1	-	16	[pcs.]
Gripping time		-	0.35	-	[s]
Releasing time		-	0.20	-	[s]
Foot-inch-foot		-	1.40	-	[s]
Vacuum pump		Integrated, electric BLDC			
Arms		4, adjustable by hand			
Dust filters		Integrated 50µm, field replaceable			
IP Classification		IP54			
Dimensions (folded)		105 x 146 x 146 4.13 x 5.75 x 5.75		[mm] [inch]	
Dimensions (unfolded)		105 x 390 x 390 4.13 x 15.35 x 15.35		[mm] [inch]	
Weight		1.62 3.57		[kg] [lb]	

Operating Conditions	Minimum	Typical	Maximum	Unit
Power supply	20.4	24	28.8	[V]
Current consumption	50	600	1500	[mA]
Operating temperature	0	-	50	[°C]
	32	-	122	[°F]
Relative humidity (non-condensing)	0	-	95	[%]
Calculated MTBF (operating life)	30.000	-	-	[hours]

Positioning the VG10 arms

The arms can be folded to the preferred position simply by pulling in the arms. The torque needed to overcome the friction in the rotatable joints of the arm is high (6 N/m) to ensure that the arms do not move when handling 10 kg payloads.

The VG10 suction cups are grouped into two independent channels.




When the four arms are adjusted to preferred angles, it is recommended to add the accompanied arrow stickers. This allows for easy realignment and exchanging between different work items.



Vacuum cups and fittings

It is possible to change suction cups simply by pulling them off the fittings. Unused holes can be blinded using a blind screw, and each fitting can be changed to a different type to match the desired suction cup. Use a 3 mm Allen key for changing to blind screws or another type of fitting.



The thread size is the commonly used G1/8"; allowing for standard fittings, blinders and extenders to be fitted directly to the VG10 arms and housing, see mechanical details in the 7.2.

Choosing the right vacuum cups for your application is essential. The VG10 comes with common 30 mm silicone vacuum cups which are good for hard and flat surfaces, but not good for uneven surfaces and it might leave microscopic traces of silicone on the workpiece which can cause issues with some types of painting processes afterwards. Below is a table with general recommendations.

Workpiece surface	Vacuum cup shape	Vacuum cup material
Hard and flat	Normal or dual lip	Silicone or NBR
Soft plastic or plastic bag	Special plastic bag type	Special plastic bag type
Hard but curved or uneven	Thin dual lip	Silicone or soft NBR
To be painted afterwards	Any type	NBR only
Varying heights	1.5 or more bevels	Any type



NOTE:

It is recommended to consult a vacuum cup specialist to find the optimal vacuum cup where the standard types are insufficient.

Payload, vacuum and air flow


The lifting capacity (payload) of the VG10 depends primarily on the following parameters:

- Suction area
- Vacuum
- Air flow

These three parameters are explained in the following subsections.

Suction area

The higher suction area, the higher lifting capacity. Be aware that the actual suction area is smaller than the outer diameter of your vacuum cups, as the vacuum cup lips forms around the workpiece, the actual suction area is reduced (see figure below)



With a typical vacuum of 60% and one vacuum cup with a 200 mm² suction area, the lifting force is:

$$F_{cup} = p \cdot A = [\Delta Pa] \cdot [m^2] = 60\% \cdot 101.3kPa \cdot 10^3 \cdot 200 \text{ mm}^2 \cdot 10^{-6} = 12.2 \text{ N}$$

With this force per vacuum cup, to lift 10 kg and accelerate with 2g's, this many vacuum cups are needed:

$$\text{Number of cups} = \frac{m \cdot a}{F_{cup}} = \frac{[kg] \cdot [m/s^2]}{[N]} = \frac{10 \cdot 2 \cdot 9.81}{12.2} = 16 \text{ vacuum cups}$$

It is often a good idea to use more vacuum cups than needed, to accommodate for vibrations, leaks and other unexpected conditions. However, the more vacuum cups, the more air leakage (air flow) is expected and the more air is moved in a grip resulting in longer gripping times.

Vacuum

Vacuum is defined as the percentage of absolute vacuum achieved relative to atmospheric pressure, i.e.:

% vacuum	Bar	kPa	inHg	Typically used for
0%	0.00rel. 1.01 abs.	0.00rel. 101.3 abs.	0.0rel. 29.9 abs.	No vacuum / No lifting capacity
20%	0.20rel. 0.81 abs.	20.3rel. 81.1 abs.	6.0rel. 23.9 abs.	Cardboard and thin plastics
40%	0.41rel. 0.61 abs.	40.5rel. 60.8 abs.	12.0rel. 18.0 abs.	Light workpieces and long suction cup life span
60%	0.61rel. 0.41 abs.	60.8rel. 40.5 abs.	18.0rel. 12.0 abs.	Heavy workpieces and strongly secured grips
80%	0.81rel. 0.20 abs.	81.1rel. 20.3 abs.	23.9rel. 6.0 abs.	Max. vacuum. Not recommended

The vacuum percentage setting is the target vacuum. The pump will run at full speed until the target vacuum is achieved, and then run at a lower speed necessary to maintain the target vacuum.


The pressure in the atmosphere varies with weather, temperature and altitude. The VG10 automatically compensates for altitudes up to 2km, where the pressure is about 80% of sea level.

Air flow

Air flow is the amount of air that must be pumped to maintain the target vacuum. A completely tight system will not have any air flow, whereas real life applications have some smaller air leakages from two different sources:

- Leaking vacuum cup lips
- Leaking workpieces

The smallest leak under a vacuum cup can be hard to find (see picture below).




Leaking workpieces can be even harder to identify. Things that look completely tight might not be tight at all. A typical example is coarse cardboard boxes. The thin outer layer is often requiring a lot of air flow to create a pressure difference over it (see figure below).



Therefore, the users must be aware of the following:

- VG10 is not suitable for most uncoated, coarse cardboard boxes.
- Extra attention must be paid to leakages, e.g. vacuum cup shape and surface roughness

The air flow capability of a VG10 is shown in the graph below:



NOTE:

The easiest way to check if a cardboard box is sufficiently tight is simply to test it using the VG10.

A high vacuum percentage setting does not give a higher lifting capacity on corrugated cardboard. In fact, a lower setting is recommended, e.g. 20%.

A low vacuum setting results in less air flow and less friction below the vacuum cups. This means VG10 filters and vacuum cups will last longer.

7.2 Mechanical Drawings


7.2.1 Adapter plate(s)

No adapter plates are required.

7.2.2 Mountings

	Quick Changer - Robot side	89
	Dual Quick Changer.....	90
	HEX-E QC.....	91


Quick Changer - Robot side



* Distance from Robot flange interface to OnRobot tool.

All dimensions are in mm and [inches].


Dual Quick Changer



* Distance from Robot flange interface to OnRobot tool

All dimensions are in mm and [inches].

HEX-E QC




* Distance from Robot flange interface to OnRobot tool
All dimensions are in mm and [inches].

7.2.3 Tools


	Gecko	92
	RG2-FT	93
	RG2	94
	RG6	95
	VG10	96
	Quick Changer - Tool side	98

Gecko




All dimensions are in mm and [inches].

RG2-FT




All dimensions are in mm and [inches].

RG2




All dimensions are in mm and [inches].

RG6




All dimensions are in mm and [inches].

VG10




All dimensions are in mm and [inches].



All dimensions are in mm and [inches].

Quick Changer -
Tool side



All dimensions are in mm and [inches].

7.3 Center of Gravity

COG, TCP, and weight parameters of the single devices (without any mounting/adapter):

Devices	Coordinate system	TCP [mm]	Center of Gravity [mm]	Weight
HEX-E/H QC		X=0 Y=0 Z=50	cX=0 cY=5 cZ=20	0.35 kg 0.77 lb
Gecko Gripper		X=0 Y=0 Z=187	cX=0 cY=0 cZ=113	2.83 kg 6.10 lb
RG2-FT*		X=0 Y=0 Z=205	cX=0 cY=0 cZ=65	0.98 kg 2.16 lb
RG2*		X=0 Y=0 Z=200	cX=0 cY=0 cZ=64	0.78 kg 1.72 lb
RG6*		X=0 Y=0 Z=250	cX=0 cY=0 cZ=90	1.25 kg 2.76 lb
VG10**		X=0 Y=0 Z=105	cX=15 cY=0 cZ=54	1.62 kg 3.57 lb

* Mounted at 0°

** With arms folded back

8 Maintenance



WARNING:

An overall inspection of the OnRobot's End of Arm Tooling must be performed regularly and at least once every 6 months. This inspection must include but is not limited to check for defective material and clean gripping surfaces.

Use original spare parts, and original service instructions for the OnRobot's End of Arm Tooling and the robot. Failure to comply with this precaution can cause unexpected risks, resulting in severe injury.

If you have questions regarding spare parts and repair, please visit our website www.onrobot.com to contact us.

📖 Gecko	100
📖 RG2/6	102
📖 RG2-FT	102
📖 VG10	102

Gecko

Gecko Gripper pads are made from a precision cast silicone or polyurethane film with a gecko microstructure. Contact with sharp objects may damage the pad surface and impair function. The Gecko Gripper performance is maximized when the pads are clean and dry. The pads can collect dust, so it is best to use the Gecko Gripper in a clean environment and/or establish a routine cleaning schedule.


Part	Description of Maintenance	Frequency
Pad Cleaning	Routine cleaning: Cleaning Station	Dependent on operating conditions. Guidelines are: See Cleaning Station User Guide
Pad Wear	Replacement due to wear	150000 – 200000 for HIGH preload operation 200000 – 250000 for LOW preload operation

Replacing the Gripper Pads

Gecko Gripper pads are designed to last for 200,000-300,000 cycles under typical operating conditions. If the pads do not seem to be gripping properly, even with routine cleaning (see table in the previous page), we recommend fully replacing the gripper pads.

To replace the gripper pads, use the provided pad removal tool.


Step 1: Move gripper pads to the maximum extruded setting such that the pads are maximally exposed/visible.



Step 2: Insert the edge of the pad removal tool between the shiny silver plate of the pads and the dull backing plate. Leverage the pad removal tool against the gripper housing to pry off the used pad. Repeat for all pads.



Step 3: To install new replacement pads, align the notch of the pad with the tab in the mounting hole. Push the pad into the gripper until there are no gaps between the shiny silver pad plate and backing plate.



RG2/6**WARNING:**

An overall inspection of the PLd CAT3 Safety Buttons must be performed regularly and at least once every 6 months.

RG2-FT**WARNING:**

Please clean the proximity sensor surface regularly with low pressure compressed air (<5 bar) from a 5 cm distance. For stronger contamination use isopropyl alcohol with a soft cotton swab to keep it clean.

VG10

The VG10 is equipped with one filter for each suction cup socket, and one filter for the exhaust. How often the filters need to be changed depends on the nature of the work piece and the working environment. The VG10 automatically de-dust the filters every time a grip is released. However, particles can eventually get stuck and build up inside the filter, lowering the VG10 performance.

A filter service kit is available, which include both new filters and tools needed.

- Filter service kit, PN 100064

Neither use nor power on the VG10 without filters. Dust, hair and larger particles can get stuck in pump membranes and valve seats, causing permanent damage to the VG10.

**DANGER:**

Identify how often the filters need service and schedule maintenance with a fixed period short enough to ensure a firm grip at all times.

An overall inspection of the VG10 must be performed regularly and at least once every 6 months.

Never power the VG10 without filters or with filters mounted incorrectly. Failure to comply with this precaution can cause irreversible failure of pump or valves.

9 Warranties

9.1 Patents

Products of OnRobot A/S are protected by several patents; some still in global publication process (Patents pending). All manufacturers of copies and similar products violating any patent claims will be prosecuted.

9.2 Product Warranty

Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a manufacturer's warranty under the conditions set out below:

In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 12 months of entry into service (maximum of 15 months from shipment), OnRobot A/S shall provide the necessary spare parts, while the customer (user) shall provide working hours to replace the spare parts, either replace the part with another part reflecting the current state of the art, or repair the said part. This warranty shall be invalid if the device defect is attributable to improper treatment and/or failure to comply with information contained in the user guides. This warranty shall not apply to or extend to services performed by the authorized dealer or the customer themselves (e.g. installation, configuration, software downloads). The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the warranty. Claims under the warranty must be submitted within two months of the warranty default becoming evident. Ownership of devices or components replaced by and returned to OnRobot A/S shall vest in OnRobot A/S. Any other claims resulting out of or in connection with the device shall be excluded from this warranty. Nothing in this warranty shall attempt to limit or exclude a customer's statutory rights nor the manufacturer's liability for death or personal injury resulting from its negligence. The duration of the warranty shall not be extended by services rendered under the terms of the warranty. Insofar as no warranty default exists, OnRobot A/S reserves the right to charge the customer for replacement or repair. The above provisions do not imply a change in the burden of proof to the detriment of the customer. In case of a device exhibiting defects, OnRobot A/S shall not be liable for any indirect, incidental, special or consequential damages, including but not limited to, lost profits, loss of use, loss of production or damage to other production equipment.

In case of a device exhibiting defects, OnRobot A/S shall not cover any consequential damage or loss, such as loss of production or damage to other production equipment.

9.3 Disclaimer

OnRobot A/S continues to improve reliability and performance of its products, and therefore reserves the right to upgrade the product without prior warning. OnRobot A/S ensures that the content of this manual is precise and correct but takes no responsibility for any errors or missing information.

10 Certifications



CERTIFICATE

on the inspection of a product manufacturing facility
applied for TÜV NORD CERT approval marks

OnRobot A/S
Teglværksvej 47H
5220 Odense SØ
Denmark

Manufacturing facility: **OnRobot A/S**
Teglværksvej 47H
5220 Odense SØ
Denmark

Products: **Gripper RG2 v2 and RG6 v2**

Date of inspection: **07.05.2019**

Inspection summary:
The applicant was able to demonstrate that the manufacturing facility is technically equipped and managed in such a way that uniform production is guaranteed for the listed product(s).

Certificate Registration No. 44 786 190827	Validity
ZA-No. 3524 6146	from 2019-05-07
Project-No. 8003006488	until 2020-05-06



Certification Body
at TÜV NORD CERT GmbH

Essen, 2019-06-03

TÜV NORD CERT GmbH Langemarckstraße 20 45141 Essen www.tuev-nord-cert.de technology@tuev-nord.de

